


MORLEY  **IAS**
FIRE SYSTEMS

ZX1e

ZX2e

ZX5e

Document No. 996-130 Issue 01

**user
manual**

Table of Contents

1	INTRODUCTION	4
1.1	NOTICE	4
1.2	WARNINGS AND CAUTIONS	4
1.3	NATIONAL APPROVALS	4
2	USER CONTROL LEVELS	5
2.1	LEVEL DEFINITION	5
2.2	USER PASSWORDS	5
3	CONTROLS AND DISPLAYS	6
3.1	CONTROL KEYS	6
3.2	FRONT PANEL LED INDICATIONS	7
3.3	ALPHANUMERIC DISPLAY INDICATIONS	9
3.3.1	<i>Normal Condition</i>	9
3.3.2	<i>Display Examples – Fire Alarms</i>	9
3.3.3	<i>Display Examples – Faults</i>	9
4	LEVEL 1 DISPLAY / CONTROL FUNCTIONS	10
4.1	NORMAL CONDITIONS	10
4.2	AC MAINS POWER FAIL CONDITIONS	10
4.3	FIRE ALARM CONDITIONS	10
4.3.1	<i>Override Delays</i>	10
4.4	FAULT CONDITIONS	10
5	LEVEL 2 CONTROL FUNCTIONS	11
5.1	POWER FAILURE CONDITION	11
5.1.1	<i>AC Mains Power Failure Indication</i>	11
5.1.2	<i>Battery Low / Charger Failure</i>	11
5.2	FAULT CONDITIONS	12
5.2.1	<i>Fault Indication</i>	12
5.2.2	<i>User Actions</i>	12
5.3	FIRE ALARM CONDITIONS	12
5.3.1	<i>Fire Alarm Indications</i>	12
5.3.2	<i>User Actions</i>	12
5.4	USER OPTION FUNCTIONS	13
5.4.1	<i>Test</i>	14
5.4.1.1	LED Test	14
5.4.1.2	LCD Test	14
5.4.1.3	Zones Test	14
5.4.1.3.1	<i>Configuring the Test</i>	14
5.4.1.3.2	<i>Terminating the Test</i>	15
5.4.1.3.3	<i>Inspecting Other Conditions During a Walk Test</i>	16
5.4.1.4	Output Test	16
5.4.1.5	Audible Indicator Test	17
5.4.2	<i>Time</i>	17
5.4.3	<i>Enable / Disable Functions</i>	17
5.4.3.1	Enable or Disable Zones	18
5.4.3.2	Enable or Disable Inputs	18
5.4.3.3	Enable or Disable Keys	19
5.4.3.4	Enable or Disable Delayed Day Modes	20
5.4.3.4.1	<i>Configure Day Mode Delay Period / Disable Operation</i>	20
5.4.3.4.2	<i>Manual Override</i>	20
5.4.3.5	Enable or Disable Outputs	21
5.4.3.6	Enable or Disable Delays	21
5.4.4	<i>Print</i>	22
5.4.5	<i>View</i>	23
6	DELAYED DAY MODE OPERATION	24

7 LEVEL 3 PROGRAMMER FUNCTIONS.....24

8 LOG BOOK.....25

Table of Figures

FIGURE 1 – ZX1E, ZX2E CONTROLS AND DISPLAYS.....6

FIGURE 2 - ZX5E CONTROLS AND DISPLAYS.....6

FIGURE 3 - SYSTEM CONTROL LED DISPLAY7

Table of Tables

TABLE 1 – CONTROL KEY FUNCTIONS.....6

TABLE 2 - ALPHANUMERIC AND INTERACTIVE CONTROL KEYS7

TABLE 3 - LED FUNCTIONS8

TABLE 4 - USER MENU OPTIONS13

TABLE 5 - VIEW MODE OPTIONS23

TABLE 6 - LOGBOOK REFERENCE DATA25








TABLE 7 - LOGBOOK EVENT DATA.....26

1 Introduction

1.1 Notice

- The material and instructions covered in this manual have been carefully checked for accuracy and are presumed to be correct. However, the manufacturer assumes no responsibility for inaccuracies and reserves the right to modify and revise this document without notice.
- These instructions cover the use and operation of the Fire Alarm Control Panel. Refer to the Installation Manual (P/N 996-131) for details of how to install the system and refer to the Commissioning Manual (P/N 996-132) for information on programming and Level 3 functions.
- The ZX1E, ZX2E and ZX5E Fire Alarm Control Panels are 1, 1-2 and 1-5 loop panels for use with analogue addressable devices from the following detector manufacturer ranges: -

For use with software version 800 onwards

	Apollo	
	Hochiki	
	Morley-IAS	
	Nittan	
	System Sensor	

1.2 Warnings and Cautions



These instructions contain procedures to follow in order to avoid injury and damage to equipment. It is assumed that the user of this manual has been suitably trained and is familiar with the relevant regulations.



All equipment is to be operated in accordance with the appropriate standards applicable

1.3 National Approvals

This equipment must be installed and operated in accordance with these instructions and the appropriate national, regional and local regulations specific to the country and location of the installation. Consult with the appropriate Authority Having Jurisdiction (AHJ) for confirmation of the requirements.

**EN54-2 13.7**

Maximum of 512 sensors / manual call points per panel.

- The ZX1E, ZX2E & ZX5E range of panels has many features, which if used inappropriately, may contravene the requirements of EN54. Where such a possibility may arise, a suitable warning is given with brief details of the EN54 requirement and the relevant section it pertains to. A typical EN54 non-compliance warning is illustrated.

2 User Control Levels

2.1 Level Definition

- The ZX1E, ZX2E and ZX5E Fire Alarm Control Panels have three user control levels.
- At all three levels, the LED Displays indicate the condition of the installation, the Zone LED Displays indicate the location of any fire alarm or fault and the alphanumeric display gives more detailed fire alarm or fault information.
- At USER LEVEL 1, all the displays are functional but the front panel control keys are inhibited.
- At USER LEVEL 2, all front panel controls are functional and some system operation parameters and functions can be changed. User Level 2 is reached by entering a password from level 1.
- At USER LEVEL 3, all front panel controls are functional and full system configuration and programming is possible. User Level 3 is reached by entering a password from either Level 1 or Level 2. User Level 3 is intended for use by the system installer / maintenance contractor.

2.2 User Passwords

- Up to ten USER LEVEL 2 passwords can be programmed into the panel.
- The USER LEVEL 2 passwords can be assigned / changed at Level 3 by the installer / maintenance contractor. Level 2 passwords do not allow access to Level 3 functions.

3 Controls and Displays

3.1 Control keys

- The control panel has two groups of control keys.
- A bank of five keys contains the four system control keys: Sound Alarms, Silence / Resound, Mute, Accept and System Reset.
- A bank of 17 keys contains interactive and alphanumeric keys.




Figure 1 – ZX1E, ZX2E Controls and Displays

Figure 2 - ZX5E Controls and Displays

Key Legend	Symbol	Function
Sound Alarms		Press to Turn on ALL Sounder Outputs (i.e. evacuate building manually).
Silence / Resound		Press to Turn off all activated sounders. Press again to re-activate the sounders.
Mute Buzzer		Press to silence the internal buzzer.
Accept		Press to accept a Stage 1 Investigation Delay Alarm
System Reset		Press to cancel all alarm conditions and reset the panel.

Table 1 – Control Key Functions

- The alphanumeric keys normally function as a numeric keypad. During programming, these keys can be toggled to Letter Keys by pressing the CHANGE key. This gives access to letters A-M. For access to letters N-Z, press and hold the SHIFT key whilst pressing the appropriate letter key.






Key Legend	Symbol	Function
0 to 9		Press to enter numbers 0-9 or letters A-J (N-W with Shift)
>		Press to scroll through fire alarms or faults manually on the display or letter K (X with Shift)
<		Press to scroll back through fire alarms or faults manually on the display or letter L (Y with Shift)
Change		Press to change a display option (where allowed) or letter M (Z with Shift)
Enter		Press to confirm entry of a multiple digit number
No		Press to answer No, or terminate a display option
Yes		Press to answer Yes, or step through a display option
Shift		Press to show user options on the display Press, during programming, to allow entry of Letters N-Z

Table 2 - Alphanumeric and Interactive Control Keys

- The control keys are disabled at USER LEVEL 1. Pressing the SHIFT key will cause the display to prompt for entry of the Level 2 password. The password must be entered to re-enable the control keys at Level 2.

3.2 Front Panel LED Indications

- The Level 1 LED Indicators are divided into two sections.
- The upper array of LED Indicators shows the operational conditional of the panel and the installation.
- The lower array of Zone LED indicators shows the location of a fire alarm or fault.
- The standard Zone LED Indicators provide identification for up to 20 zones. On the ZX5E panel, this can be extended by adding either a further 20 zones (to give a total of 40 zones) or a further 60 zones (to give a total of 80 zones).
- The LED Indicators illuminate as red, yellow or green to give a clear indication of the panel status as follows:




Figure 3 - System Control LED Display

Indicator	Colour	Function	How to Clear
FIRE	Red	The panel has detected a fire alarm condition, or the 'Sound Alarms' key has been pressed.	Correct the condition causing the alarm and then perform a panel reset.
Fault	Yellow	The panel has detected a fault.	Correct the condition causing the fault and then perform a panel reset.
Acknowledged	Yellow	A fault or alarm has been acknowledged and the internal buzzer silenced.	Correct the condition causing alarm or fault and then perform a manual reset. NOTE: If another alarm or fault occurs, the internal buzzer automatically resounds.
Disablement	Yellow	Part of the system, either input or output, has been disabled manually by the user.	Re-enable the device or devices. Refer to Disablement Function.
Test	Yellow	The system is in test mode. Zone LED indicators show which zones are being tested.	Cancel test when finished.
Sounder Fault	Yellow	This indicates a wiring fault with one of the sounder output circuits.	Correct the fault condition and then perform a panel reset.
Delayed Mode	Yellow	This indicates that the system is operating with delays to the sounder outputs and the delays are active (in force).	The delays may be enabled or disabled. Refer to Disablement Function.
Relays Disabled	Yellow	The relay outputs have been disabled.	Refer to Disablement Function.
Earth Fault	Yellow	An earth connection fault has occurred on a cable.	Correct the fault condition and then perform a panel reset.
System / CPU Fault	Yellow	The CPU has reset or a system fault has occurred.	Correct the problem, if appropriate, and then perform a panel reset.
Sounders Disabled	Yellow	The sounder outputs have been disabled.	Refer to Disablement Function.
Alarms Silenced	Yellow	The sounder outputs have been silenced.	Correct the alarm condition and then perform a panel reset. NOTE: Press SILENCE / RESOUND again to reactivate the sounders. If a new alarm occurs, the alarms will resound.
Supply Fault	Yellow	There is a problem with the power supply, battery or supply input.	Correct the fault condition and then perform a panel reset.
Power	Green	STEADY: Indicates AC Power is present. FLASHING: Indicates a loss of AC Power.	See Supply Fault.
Zone FIRE	Red	FLASHING: The zone is in a fire alarm condition.	Correct the alarm condition and then perform a panel reset.
Zone Fault	Yellow	FLASHING: The zone contains faulty devices. STEADY: The zone is either disabled or in test mode.	Correct the fault condition and then perform a panel reset. Re-enable devices or cancel test mode.

Table 3 - LED Functions

3.3 Alphanumeric Display Indications

- The alphanumeric liquid crystal display gives 80 characters of information on a 2-line display. The display is illuminated to assist viewing under dim ambient light conditions.
- When the numeric keypad is not in use, the display will revert to automatically scrolling through any fire alarm or fault conditions present on the panel. If there are no alarm or fault conditions, the display will show the date and time.
- Pressing the SHIFT key will show a list of optional functions or prompt for the level 2 password.

```
[Panel ACTIVE Control Keys INHIBITED] [1]
Do you want to enable the control keys?
```

3.3.1 Normal Condition

```
03-Oct-2001 11.38
All devices are inside working limits.
```

3.3.2 Display Examples – Fire Alarms

```
1 of 1 FIRE [1]
ALARM RAISED FROM CONTROL PANEL
```

```
2 of 2 FIRE MCP L2 A002 [1]
< - Zone Text - > < - Device Text - >
```

3.3.3 Display Examples – Faults

```
1 of 1 [1]
OPEN CIRCUIT ON SOUNDER B
```

```
2 of 8 No reply L2 A001 [1]
< - Zone Text - > < Device Text - >
```

This number is the panel address number assigned to the panel in a network system.

4 Level 1 Display / Control Functions

- At Level 1, the panel operates in a display only mode with the control keys disabled.
- If fire alarm or fault conditions exist, the LED Indicators will show these. Detailed information will be scrolled on the alphanumeric display.
- The information on the alphanumeric display can be scrolled manually by pressing either the > (forward) or the < (back) keys.

4.1 Normal Conditions

- When the system is in a normal condition, the green AC Power LED will be illuminated. The alphanumeric display will show the time and date and will alternate between a user programmed text message and a system status message.


4.2 AC Mains Power Fail Conditions

- If the AC MAINS power source is interrupted, the AC Power LED will flash. In addition, the internal buzzer will sound.
- The back light illumination of the alphanumeric display will be turned off, the display will show an “AC Fail” message and the Supply Fault LED and Fault LED Indicators will be lit.
- If both the AC MAINS input and the Battery Standby Input fail then all LED and alphanumeric display indicators will be off.

4.3 Fire Alarm Conditions

- If the control panel initiates an alarm condition, the FIRE LED Indicators will be illuminated and, if appropriate, the relevant ZONE FIRE LED Indicators will flash. The internal buzzer will sound and the alphanumeric display will give detailed information regarding the fire alarm location.
- If more than one fire alarm condition is present, the alphanumeric display will either automatically scroll through or, can be manually scrolled through, the fire alarms registered.

4.3.1 Override Delays



- If the ZX1E, ZX2E and ZX5E control panels are configured to operate with delays to outputs, a manual call point (MCP) will be located next to the panel.
- To override any delays and immediately activate the bells and other fire alarm output devices, break the glass in the call point.



4.4 Fault Conditions

- If the panel detects a fault, the FAULT LED is illuminated along with other appropriate system condition LED Indicators. The alphanumeric display gives detailed information regarding the nature of the fault and the panel buzzer will sound.
- If more than one fault condition is present, the alphanumeric display will either automatically scroll through or, can be manually scrolled through, the faults registered.

5 Level 2 Control Functions

- All of the functions and operational features described for Level 1 user are available and are the same for a Level 2 user.
- To enable Level 2 operation, press the SHIFT key. The display will then show:

```
[Panel ACTIVE Control Keys INHIBITED] [1]
Do you want to enable the control keys?
```

- Press the **YES** key and the display will prompt for entry of the password.

```
[Panel ACTIVE Control Keys INHIBITED] [1]
Please Enter Password
```

- Enter the **4-digit Level 2 password**. The display then shows the Main Menu of user options.

```
[ACTIVE] 1)Commission 2)Test 3)Time [1]
4)Enable 5)Disable 6)Print 7)View
```

- If a key has not been pressed for a certain period, the display will revert to the normal Level 1 display showing the system status message. To re-show the menu display, press the **SHIFT** key.
- If a key has not been pressed for a specified period of time, (normally 5 minutes – programmable), then 'Level 2' access will be automatically cancelled. It will be necessary to re-enter the password to re-activate Level 2 functions.

5.1 Power Failure Condition

5.1.1 AC Mains Power Failure Indication

- If the AC MAINS input is interrupted, the AC Power LED will flash and the panel buzzer will sound.
- The back light illumination of the alphanumeric display will be turned off, the alphanumeric display will show an 'AC Fail' message and the Supply Fault LED Indicator will be lit.
- If both the AC MAINS input and the Battery Standby Input fail then all LED and alphanumeric display indicators will be off.
- To silence the panel buzzer, press the **MUTE BUZZER** key.
- When the AC MAINS is restored, the AC Power LED returns to steady on.
- To clear the latched AC MAINS Fault, press the **SYSTEM RESET** key.
- When MUTED, the buzzer will continue to sound a short beep every 30 seconds. This gives an on-going warning of the continued AC Mains Failure condition.

5.1.2 Battery Low / Charger Failure

- If the battery becomes disconnected or the battery voltage is less than 21V DC or if there is a failure in the circuitry that charges the battery, then the panel shows a 'Battery Low / Charger Failure' message.
- To silence the panel buzzer, press the **MUTE BUZZER** key.
- To clear the latched Fault, press the **SYSTEM RESET** key. If the fault is still present it will be redisplayed.

5.2 *Fault Conditions*

5.2.1 Fault Indication

- If the panel detects a fault, the **FAULT LED** is illuminated along with other appropriate system condition LED Indicators. The alphanumeric display gives detailed information regarding the nature of the fault and the panel buzzer will sound.

5.2.2 User Actions

- To acknowledge the event and to silence the panel buzzer, press the **MUTE BUZZER** key. The **ACCEPTED LED** will then be illuminated.
- The panel will not allow a reset until the source of the fault is corrected. If necessary, the panel allows the disabling of individual points and zones.
- After correcting the problem, press the **SYSTEM RESET** key. The **FAULT**, **ACCEPTED** and other appropriate system status LED Indicators will be turned off. The alphanumeric display returns to normal mode.

5.3 *Fire Alarm Conditions*

- The panel will indicate a fire alarm condition if it detects an alarm condition or if the **SOUND ALARMS** key is pressed.

5.3.1 Fire Alarm Indications

- If the control panel initiates an alarm condition, the **FIRE LED Indicator** will be illuminated and, if appropriate, the relevant **ZONE FIRE LED Indicators** will flash. The internal buzzer will sound and the alphanumeric display will give detailed information regarding the fire alarm location.
- To test the alarm system, or to evacuate the building, press the **SOUND ALARMS** key. The panel will activate all the sounder output circuits, will illuminate the **FIRE LED Indicator** and the alphanumeric display will indicate a 'Manual Evacuation'.

5.3.2 User Actions

- Press the **MUTE BUZZER** key to acknowledge the event and to turn off the internal buzzer. The **ACCEPTED LED** is turned on.
- Press the **SILENCE / RESOUND** key to silence the sounder output circuits. The **SOUNDERS SILENCED LED** is turned on. Press the **SILENCE / RESOUND** key again to reactivate the sounder outputs.
- Press the **SYSTEM RESET** key to reset the system.

5.4 User Option Functions

[ACTIVE] 1)Commission 2)Test 3)Time [1]
4)Enable 5)Disable 6)Print 7)View

- The optional functions available to the user at Level 2 are as follows:

Function	Description
Commission	This option is not available to Level 2 users. It requires the entry of the Level 3 password before the programming mode can be entered.
Test	Allows the user to test parts of the system. The following tests can be performed: LED To test the LED indicator lamps. This test will automatically test each zone indicator and then terminate. LCD To test the alphanumeric display. ZONES To perform a 'Walk Test' on one or more zones. OUTPUTS To test the relay and sounder outputs connected to the system. This test is only available to Level 3 users.
Time	To change the date and time in the panel.
Enable	To enable zones, inputs, outputs, delays and day mode operation.
Disable	To disable zones, inputs, outputs, keys, delays and day mode operation.
Print	To print various reports on an internal or remote printer.
View	To view devices and system status conditions.

Table 4 - User Menu Options

5.4.1 Test

- To display the Test Menu, press '2' and the display shows:

```
1)LEDs  2)LCD  3)Zones  4)Outputs
5)Audible Indicator
```

- The test menu allows the user to test:
 1. The LED's on the front panel display.
 2. The alphanumeric (liquid crystal) display.
 3. The detection and alarm initiating devices connected to the signaling loop.
 4. The sounder outputs and other alarm condition output devices connected to the system.
 5. The internal buzzer.

5.4.1.1 LED Test

- To select the option, press '1'.
- To terminate the test, press **No**.
- The panel will flash all of the indicators on the LED Display and will step through all of the Zone FIRE and FAULT indicators.

5.4.1.2 LCD Test

- To select the option, press '2'.
- To terminate the test, press **No**.
- The alphanumeric display will flash all displayable characters in all positions of the display and then return to the menu.

5.4.1.3 Zones Test

5.4.1.3.1 Configuring the Test

- The 'Walk Test' option allows the user to conveniently test the detection and alarm initiating devices without having to continually reset the panel.
- To select the option, press '3'.



If no action is taken at this point, the display will automatically revert to the normal display after 1 minute. Pressing SHIFT or > will return the display to the test display.

- The display will then prompt for whether the sounder outputs should ring:

```
Ring Bells?
```

- Press **Yes** and the sounders (dependent on their programming) will ring for a few seconds and then be reset automatically when a device is tested. (NOTE: Relay Outputs are never activated).
- Press **No** and the sounders will not ring.
- The panel can be set to test a range of zones. The display will prompt for the first zone to be tested:

```
Test from zone?
(Please key in number, then press "Enter")
```

- Key in the number of the first zone to be tested. For example, for zone 12, press '**12 ENTER**'.
- The display then prompts the last zone to be tested:

```
Test from zone 12    to zone ?
(Please key in number, then press "Enter")
```

- Key in the number of the last zone to be tested. For example, for zone 15, press '**15 ENTER**'.
- The 'Walk Test' is then entered and the display will show a scrolling 'W' alternating with a 'Press No to Exit' on the bottom line:


```
Test from zone 12    to zone 15
-----W-----
```



When the display indicates that the panel is in 'Walk Test', the display will continue to show that walk test mode is active.

- In the above example, any detector or initiating device going into alarm condition in zones 12, 13, 14 or 15 will:
 1. Display an activation message on the alphanumeric display, write the event in the event log, sound the panel buzzer and illuminate the appropriate zone FIRE LED.
 2. Turn on the LED at the sensor that initiated the alarm
 3. After a few seconds, the panel will be automatically be reset and the detector LED turned off. The panel is then ready to test the next detector. (Note: Up to 30 seconds is allowed for smoke detectors to clear).
- If an alarm signal is received from a zone other than those under test, then all sounder output and relay output circuits will activate as programmed for the zone in alarm. The sounders will continue to ring until silenced from the panel.

5.4.1.3.2 Terminating the Test

	<p>EN54-2 10.1 b</p> <p>Walk Test:</p>
---	--


- To terminate the walk test mode the '**NO**' key **MUST** be pressed.

- On exiting the walk test function, the panel shows the following message for 20 seconds:

```
Walk Test Terminating
Please wait
```

- This operation is to ensure that the test conditions (for example, smoke in the detector chamber) have cleared before returning the panel to normal operation, thereby avoiding unexpected fire alarm conditions.

5.4.1.3.3 Inspecting Other Conditions During a Walk Test



EN54-2 5.1
Display of functional conditions:

- To inspect Fire, Fault or Disablement Conditions whilst a walk test is in progress, press the '>' key.

- This returns the display to the menu options from which all other operating conditions can be inspected.
- To cancel the walk test, re-select the Zones Test Option. The display will then return to the normal walk test view, showing the current walk test in operation. For example:

```
Test from zone 12    to zone 15
-----W-----
```

- Then press the 'NO' key to cancel the test.

5.4.1.4 Output Test



Access to this test option is only available to users with the Level 3 password.

- To select the option, press '4' and then enter the password '####'.
- To terminate the test, press **No**.
- The output test allows the relays and sounders to be individually operated. The first six outputs are reserved for the panel's own onboard relay and sounder circuits as shown below:

- Output 1 – Onboard Relay 1
- Output 2 – Onboard Relay 2
- Output 3 – Onboard Sounder A
- Output 4 – Onboard Sounder B
- Output 5 – Onboard Sounder C (Only available on ZX5E panel!)
- Output 6 – Onboard Sounder D (Only available on ZX5E panel!)

- On entering the test, the display will show the current state of the first output:

```
RELAY      OPERATED
 1
```

- To advance to the next output, press the > or the **YES** key.

```
RELAY      NOT OPERATED
 2
```

- To change the output state, press the **CHANGE** key. The display will show the new state:

RELAY	OPERATED
2	



The onboard sounder circuits are constantly monitored for correct end-of-line termination. A sounder error will be reported if one of the sounders is left in the operated test state for more than 5 seconds.

5.4.1.5 Audible Indicator Test

- To select the option, press '5'.
- The buzzer will beep.

5.4.2 Time

- To change the date and time shown on the alphanumeric display, press '3' from the main user option menu.



On multi-panel systems, it is only necessary to change the time at the Master Panel. All of the other panels will synchronize their date and time to that of the master panel when a reset is performed on the master panel.

5.4.3 Enable / Disable Functions

- To select the enable or disable menu options, press '4' or press '5' as required from the user main menu. The display shows for each option:

ENABLE	1)Zone	2)Input	3)Keys
	4)Day Mode	5)Outputs	6)Delays

DISABLE	1)Zone	2)Input	3)Keys
	4)Day Mode	5)Outputs	6)Delays

- The options available in each menu are identical. This allows the user to enable or disable:
 1. Zones
 2. Individual devices
 3. Panel Keys
 4. Day Modes
 5. Outputs (Sounders or relays)
 6. Delays
- Whenever an enable operation is performed, the action is carried out but the disablement is not removed from the LCD. The following is shown momentarily on the display.

Press RESET to clear disablements from scrolling event display
--

- To clear the entries from the display event history, press the "SYSTEM RESET" button.

5.4.3.1 Enable or Disable Zones

- To enable or disable input devices by zone, select option 1.



Any loop driven output devices such as sounders or relay modules will still activate as programmed even if disabled. Only the input signal from these devices will be ignored.

- Press '1' and the display will prompt for the required zone number.

```
Disable Zone      ?  
( Enter number or use ">" to scroll )
```

- Key in the zone number and then press the **ENTER** key. Or use the > key to scroll through the zones.

```
Disable Zone 14  OK ?
```

- The display will then repeat the zone number and ask for confirmation (OK?). Press the **YES** key to confirm.
- The panel will enable or disable all of the input devices in the zone including smoke, temperature and call points.
- When a zone is disabled, the **DISABLEMENT** LED and the corresponding yellow **Zone FAULT** LED will be illuminated.

(NOTE: If the panel is installed and programmed to operate in accordance with BS5839 then disabling a zone does NOT disable call points within that zone).

5.4.3.2 Enable or Disable Inputs

- To enable or disable individual input devices, select option 2.



Any loop driven output devices such as sounders or relay modules will still activate as programmed even if disabled. Only the input signal from these devices will be ignored.

- Press '2' and the display will prompt for the signalling loop circuit number where the device is located.

```
Loop _
```

- Enter the required loop number (1 for ZX1E, 1-2 for ZX2E or 1-5 for ZX5E) and the display will prompt for the numeric address of the device:

```
Loop 2  Address ____
```

- Enter the address of the device required. If the address is less than 3-digits long (for example address 34), this can be entered as either **034** or **34** followed by **ENTER**.
- The display will then ask for confirmation (OK?).

Loop 2 Address 34 OK ?

- Press the **Yes** key to confirm.
- When an individual point is disabled, the DISABLEMENT LED will be illuminated.
- The corresponding Zone FAULT LED will only be illuminated if all devices in the zone are disabled.

Networked Panels

- Master panels are able to command other panels to enable or disable individual devices.
- In this case, the display will prompt with an additional, opening question requesting the panel (CPU) number.

CPU __

- Enter the address of the required panel. The display will then prompt for the loop and device address information as described above.

5.4.3.3 *Enable or Disable Keys*

- To disable the panel control keys, press '3' from the disable menu.
- The user Level 2 password will then be required to re-enable the panel control keys and provide access to the User Option Functions.



The panel keys will be automatically disabled if a key has not been pressed for a pre-programmed period.

5.4.3.4 Enable or Disable Delayed Day Modes

- The Delayed Day Mode operation is configured at Level 3 by the installer / maintenance contractor.
- For example, the Delayed Day Mode may be set to be active between 8:00 and 17:00. Outside of these hours, a fire alarm condition will immediately sound the bells and activate outputs.
- The Delayed Day Mode causes the panel to respond to high sensor signals by sounding the panel buzzer and displaying a warning message on the alphanumeric display. The panel delays the activation of the alarm condition outputs (sounders or relays) for a programmed period.
- The user may enable or disable the operation of the Delayed Day Mode through the Enable or Disable Menus.
- To select Delayed Day Mode, press '4' from the Enable or Disable Menus. The display now presents two options:

Disable:

```
1)Configure the Day Mode Delay Period
2)Temporary Override - Turn Off Delays
```

Enable:

```
1)Disable the Day Mode Delay Period
2)Temporary Override - Turn On Delays
```

5.4.3.4.1 Configure Day Mode Delay Period / Disable Operation

- To select configure or disable options, press '1'.
- When enabling the operation of the Delayed Day Mode function, the display prompts for the number of days the Delayed Day Mode is to be in operation.

```
Use day mode for the next 2 days OK ?
```

- If the prompted number of days is not as required, press the **CHANGE** key and then enter the required number of days.
- In the above example, the Delayed Day Mode will be effective for today and tomorrow. The day after tomorrow, the panel will go immediately into a full fire alarm condition on receiving a high signal from a device.
- The number of days can be selected in the range 001 to 199. To permanently enable the Delayed Day Mode operation, enter the number of days as 200.
- When Disable Day Mode Delay is selected, the Stage 1 / 2 Day Mode Delay Function is completely turned off.

5.4.3.4.2 Manual Override

- The manual override facility provides a means to override the scheduled time clock for operation of the stage 1 / 2 Day Mode Delay.
- If the Turn-On Delays option is selected, the Stage 1 / 2 function will be turned on immediately. It will automatically turn off again at the end of the next scheduled time.
- If the Turn-Off Delays option is selected, the Stage 1 / 2 function will be immediately turned off. It will automatically turn on at the start of the next scheduled time.

5.4.3.5 Enable or Disable Outputs

- All output devices (i.e. sounders and relays) can be disabled or enabled for test purposes.
- To enable or disable an output device, press '5' from the enable or disable menus.
- The display then shows a menu of the devices available and their current enable / disable status:

1) Sounders	2) Relays
ENABLED	DISABLED

- The DISABLEMENT and either the SOUNDERS DISABLED or RELAYS DISABLED LED indicators will be illuminated when the outputs are disabled. A warning message will also be shown on the alphanumeric display.
- The sounders can only be disabled after confirmation by re-entering the Level 2 password.

5.4.3.6 Enable or Disable Delays

- If the panel has been configured to operate with (pattern) phased evacuation or delays to specific outputs it is possible to enable or disable these delays.
- Select option "6" from the Enable or Disable menus.
- If disable delays is selected, the display prompts for entry of the Level 2 password to confirm.

Disable ALL output delays
Enter Password

- Enter the password.
- The display will briefly show one of the following messages to confirm the action taken before returning to the menu.

Output Delays Enabled

Output Delays Disabled

5.4.4 Print

- To select the print menu, press '6' from the user main, option menu. The display then shows:

PRINT :	1)Devices	2)Events	5)Disabled
(-)	3)Mode	4)Setup	

- This menu controls the operation of the optional front panel printer on the ZX5E panel only. The user options are as follows:

1. Devices: Prints out the present status and text assigned to all devices on a loop.
2. Events: Prints out the contents of the event log.
3. Mode: Sets the printing mode. The current mode of operation is shown on the display.
The possible modes are:
Manual - Prints on demand only
Auto - Automatically prints faults and fire alarms as they occur
- - The printer is turned off
4. Setup: Sets the type of printer connected to the panel.
5. Disabled: Prints a list of all disabled devices.



The printer Setup option can only be performed at Level 3 by an installer / maintenance contractor.

5.4.5 View

- To select the view menu, press '7' from the user main, option menu. The display then shows:

VIEW :	1)Devices	2)Log	5)Faults
	4)Outputs	5)Disablements	6)Sys Events

- This menu allows the user to view information about the selected option on the alphanumeric display.
- After viewing an option, press **NO** to return to the view menu. From the view menu, press **NO** to return to the main options menu.
- The following View Mode Options are available:

View Option	Description of Function
1. Devices	Displays the status and text of anyone detector on a signaling loop. The panel prompts for the loop number and device address.
2. Log	Displays the contents of the event log. Events can be scrolled forwards or backwards using the > or < keys.
3. Faults	Displays the current panel fault status. The display is identical to the automatic fault / fire alarm display, but with the ability to manually scroll through all the faults using the > and < keys.
4. Outputs	Displays the required state of all output (sounder and relay) devices. Pressing the SILENCE / RESOUND key turns all sounders to an off condition.
5. Disablements	Displays a sub menu from which the following can be selected 1) Zones – Allows all zones that are in either a full or a partial state of disablement, to be viewed. 2) Inputs – Allows all inputs that are disabled, to be viewed. 3) Outputs – Allows all outputs that are disabled, to be viewed. NOTE) Pressing any button scrolls through the individual disablement conditions. Press 'NO' to return to the view menu.
6. Sys Events	The top line of the display shows the event number (1 – 999). The bottom line, immediately beneath the event number, shows whether the event is present (+) for non-latched events, (*) for latched events or (-) for inactive events.

Table 5 - View Mode Options

6 Delayed Day Mode Operation

- The panel can be configured to operate in a delayed day mode during the daytime for any specified zone.
- During this time, high sensor signals received from a detector will generate a fire alarm message on the panel but delay the ringing of the sounders. The panel will initiate a full fire alarm condition if no action is taken on this warning within a specified period.
- The use of delayed day mode must be configured at Level 3 by an installer / maintenance contractor before it is available for use at Level 2.
- The delayed day mode can be configured to only operate at specified times of the day and only in specified zones if required. The maximum time allowed acknowledging stage 1 and stage 2 times can be programmed in intervals of one second.
- Whilst the Delayed Day Mode Function is in the active period the Delayed Mode LED will be illuminated.

Stage 1

- When a fire alarm condition is detected during delayed day mode, the internal buzzer will sound. The sensor location will be shown on the display along with a warning that the panel has entered stage 1 of a delayed alarm.
- If the warning is not acknowledged, by pressing **ACCEPT**, within the time allowed for stage 1, then a full fire alarm condition will be raised and the sounder outputs will activate.
- Pressing **ACCEPT** within the time allowed will cause stage 2 of the delayed alarm.

Stage 2

- The stage 2 timer commences counting down as soon as the panel receives the initial high signal from the detector. (i.e. it commences at the same time a stage 1 begins).
- Setting the stage 2 timer to a longer period than the stage 1 timer will allow the user to investigate the cause of the alarm and take appropriate action.
- If the panel is not reset, using the **SYSTEM RESET** key, within the time allowed then a full fire alarm condition will be raised and the sounder outputs will activate.



Manual Call Points (alarm boxes) will always generate an immediate fire alarm condition regardless of any delayed day mode settings.

7 Level 3 Programmer Functions

- Refer to the Commissioning Manual (996-132) for complete information on commissioning and programming the ZX1E, ZX2E and ZX5E Fire Alarm Control Panels.

8 Log Book

- In accordance with best practice, the user should maintain a logbook to record all events resulting from or affecting the system. The logbook should be kept in a place accessible to authorized persons (preferably near the main panel).
- One or more identifiable individuals should be appointed to oversee or carry out all entries in the logbook. The names of the persons (and any changes of responsible person) should be recorded.
- All events should be properly recorded (events include real and false fire alarms, faults, pre-alarm warnings, tests, temporary disconnection's and service visits). A brief note of any work carried out or outstanding should be made.
- Sample pages of the logbook are provided here and can be photocopied to produce a suitable logbook. The sample below is for reference data (e.g. the name of the responsible person), while the sample on the next page is for the entry of event information.

REFERENCE DATA

Site Name and Address: _____	
Site Telephone Number: _____	
Responsible Person: _____	Date _____
_____	Date _____
_____	Date _____
_____	Date _____
The system was installed by: _____	Date _____
And is maintained under contract by: _____	
_____	Until _____
Contact Telephone Number: _____	if Service is Required.

Table 6 - Logbook Reference Data

EVENT DATA

Date	Time	Counter Reading	Event	Action Required	Date Completed	Initials

Table 7 - Logbook Event Data

NOTES



© MORLEY-IAS. All rights reserved.
® The MORLEY-IAS Logo is a registered trademark.
MORLEY-IAS Fire Systems, Charles Avenue,
Burgess Hill. West Sussex. RH15 9UF. England.
Web site: www.morleyias.co.uk